





RVsecure GPS Communications Hub Operating Manual

RVsecure GPS Communications Hub Operating Manual

The GPS Communications Hub comes to you ready to use and requires three easy steps.

1. Install the unit
2. Connect to your RVsecure Alarm system
3. Choose your required subscription service

Unit Indication



Charge Indicator – Power - Red

Status

- ON
- OFF

Description

- Battery is charging
- Battery fully charged

System Indicator – 4G – Blue

Status

- Constant ON
- OFF
- Quick Flash

Description

- No SIM or network connection
- Standby (system armed)
- Communicating

GPS Indicator – GPS – Green

Status

- OFF
- Quick Flash

Description

- No satellite connection or standby
- Satellite Locked

Power unit on/off

The power switch is controlled by the SIM tray. To power on, insert SIM tray, to power off remove SIM tray. Use the pop up switch next to the SIM tray to release the tray and enable removal.

Startup

Cold Start – When starting from a power off status the unit can take up to 10 minutes to achieve full communications and satellite lock.

Hot Start – When starting from a power on status the unit can take a minute to achieve satellite lock.

Installation

Mounting the unit


The unit is mounted near the alarm system and generally attached with double sided tape. The connecting cable is 900mm in length so ensure that it is in a suitable position before permanent attachment of the unit.

Mounting the Antennas

The unit has two antennas that need to be mounted and attached, the GPS antenna and the 4G antenna. Both antennas come with pre installed double sided tape on the back.


GPS – the best mounting position is either internally under the roof or externally on top of the roof.

4G – it is preferred to mount as high in the vehicle as practical for the best 4G reception.




Installing the SIM

The unit has a sim tray, remove the SIM tray and install the SIM. Return the SIM tray to its position in the unit. It is recommended to insert SIM before connecting power to the system.



Connecting to the alarm

The supplied 6 pin cable is installed to the 6 pin connector at the rear of the GPS Communications Hub and then into the 6 pin connector on the Alarm unit. The alarm supplies power to the GPS so there is no additional wiring to do. Some units may also contain an 8 pin port, this is not used. The cable has two ends, the end with the 4 wires goes into the GPS, the end with 6 goes into the alarm. The 2 spare wires are used by the alarm system (see manual).



System Start

The system will now start. Make sure that you are in an area suitable to achieve a good initial satellite lock (ie not in shed or other building).

Subscription

Each GPS unit requires a subscription service to activate. Your subscription includes the SIM, data and online functions necessary to operate the system. SMS alert options are also available.

Go to <https://shop.rvsecure.com.au> and select 'GPS Subscriptions' from the menu. This will take you directly to the subscription options. Select and complete the transaction for your chosen option.

To subscribe you will need to provide your address to receive SIM card plus the following information
RVsecure GPS kit number – Alphanumeric, on the box and on the GPS unit, GPS_XXXX
Plate Number – Registration Plate number of your Caravan/Boat
Make of Caravan/Boat
Model of Caravan/Boat
Mobile number for SMS Alarm Notifications (if Gold/Platinum Saver)
Email Address for Alarm Notifications

Upon subscription you will be sent the SIM card for the service by express post and the tracking system will notify you of your login details for the server.

Once activated you will be able to log in at <https://track.rvsecure.com.au> using the credentials supplied to you.

Alert and Tracking App

Instructions are available in the downloads section of the RVsecure website.

Online system user manual

The manual for the online system is on the system information page. Once logged in click the icon



Geo Fence note

Geo fences can be set up in the online system (not the app) but alerts/alarms will appear in both. You will have a geo-fence already setup by default.

Use of SIM

The SIM supplied for subscription is for use in the GPS system only. Any attempted use in other applications will invalidate your subscription and result in your service being immediately suspended.

Transferring ownership

Please email sales@rvsecure.com.au or complete the online transfer form to transfer ownership to a new subscriber on sale of vehicle